



**Note1**

The setup parameter dELL is dependant on the coil  
Typically a value of 3.0 is suitable for normal coils  
and 1.8 for small 'coil on plug' coils.

**Important:**

Using an incorrect value may cause overheating  
of the ignition module or weak spark

Setup	ign	1
	COIL	1
	dELL	Note 1