



Setup	ign	1
	COIL	3
	dELL	Note 1

Note 1
 The Setup Parameter dELL is dependant on the coil
 Typically a value of 3.0 is suitable for normal coils.
 For small coil on plug coil use a value of 1.8
 Important Using an incorrect value may cause
 overheating of the ignition module