


**Coil Part Number**


Diamond  
90048-52128  
FI0171  
21289 2403

**Looking into coil**




Setup	M4 M4-8	M800/M880
ign	1	FALL
COIL	Number of coils used. If wasted spark is used COIL = coils used / 2.	
dELL	2.5mS	


**M4 ECU**




**M4-8 ECU**



**M8 - ECU**




**M800 / (M880)**




**Top View of Coil**

**Part Number**  
 90048-52126  
 099700-0251  
 Denso Coil




**Looking into coil**




Setup	M4 M4-8	M800/M880
ign	1	FALL
COIL	Number of coils used. If wasted spark is used COIL = coils used / 2.	
dELL	3.0mS	


**M4 ECU**



**M4-8 ECU**




**M8 - ECU**



**M800 / (M880)**




**Top View of Coil**




**Part Number**  
90048-52136  
Diamond Coil

Setup	M4 M4-8	M800/M880
ign	1	FALL
COIL	Number of coils used. If wasted spark is used COIL = coils used / 2.	
dELL	2.5mS	


**Looking into coil**



**M4 ECU**



**M4-8 ECU**



**M8 - ECU**



**M800 / (M880)**

