




**Note**

The sensor must be oriented as shown  
Do not rotate the sensor



Signal Voltage Waveform



Siemens 5WK96041

**Note**

For wiring details refer to drawings T01 or T03

**Disk Dimensions**

Use the OEM disk  
Disk dimensional requirements not known

**MoTeC**

Title **Siemens Hall Probe Sensors**

Sheet No

Drawing No

Date 10/10/1996

Drawn TW

App

Rev A

**X11**